

- The light system is wireless and requires no power source when in use. (Except when charging)
- Turn case on side and open the legs on the bottom of the case, and lock in place.(A & B)
- 3. Stand the case on the legs. (C)
- 4. Open the case and take out the light sensors. (D)
- 5. Unfasten the velcro strap to release scoreboard. (E)
- 6. Tilt screen forward and set into groove in bottom front of case. (F & G)
- 7. Locate light sensor liners inside inflatable. Starting at the notch, take each light sensor and twist it, clockwise, into the liner until the light sensor is fully twisted inside. (**H & I**)
- 8. On scoreboard, hold power button down for 4 seconds or until the scoreboard lights up. (G) Note: If not in use for 5 minutes, the scoreboard turns off and goes into power saving mode. Hold power button down, again, for up to 4 seconds to turn back on.
- Each light sensor has its own speaker. For maximum fun and gameplay, make sure volume level is set at a comfortable level. NOTE: It is recommended to have the volume at a higher level. Adjust as necessary. (G)
- 10. Refer to game instructions below for gameplay choices. The most common game is "Light Hunter". Remember, as the game progresses, a maximum of 6 random light sensors will be on at a time.
- 11. Each of the games are shown on the games sheet. As each game is played, the scoreboard updates the points immediately. Each game will begin with 3... 2... 1... on the scoreboard with audible sounds on the speakers. If there is no sound coming from the light sensors, adjust the volume (G). At the end of each game, ALL light sensors will light up with the winning team's color, red or green, or blue if it's a tie game. The scoreboard will show the points for up to 20 seconds.
- 12. To remove the light sensors, turn counter-clockwise till the notch lines up with the sensor tab. (J). Once lined up, push the vinyl down and twist counter-clockwise while making sure the vinyl is under the sensor tab. Turn until the light sensor is out. Once light sensors are removed, reverse steps 2-6 to dis-assemble completely. Refer to video online for further help at <a href="https://youtu.be/pAJUcKCJ4Uw">https://youtu.be/pAJUcKCJ4Uw</a>
- 13. The light system will easily get 8-10 hours of use. The system may require charging again depending on the length of your event. It is recommended that the light system be **plugged in overnight** to maximize the amount of use time should the system be used the next day. The charging cord is included in the case. Make sure to plug **ALL of the light sensors in AND the scoreboard.** (K & L)

## 2nd Generation SELF-SETUP INSTRUCTIONS

























## - SETTING UP PLAYERS OR GROUPS (Refer to pics on troubleshooting sheet)

- 1. If power is OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. (1)
- 2. Press button "C" until the you find the desired mode below. Once mode is chosen, press "OK" (6), (7), (8), (9)

1P: 1 Player: This option is to be used when playing individually. All paired lights are used in this option (6)

**2P:** 2 Player: This option is to be used when playing with 2 people. All paired lights are used randomly in this option. **(7) 2P2P:** 2 players in 2 groups: This option is to be used in 2 groups. All paired lights are used in this option. (ie: Zap a Mole) **(8)** 

Before a 2P2P game begins, the system will ask you ONCE to choose the lights taking part in the game. The system will ask you to choose the RED spots first. You will then hold your hand on the spots that will be used in the RED group. Once done, hit "OK". The system will then ask you to choose the spots that will be used in the GREEN group. You will then hold your hold on the spots that will be used in the GREEN group. Once done, hit "OK".

rSt: This resets selected lights. Press "OK" to reset. Once reset, the system will automatically go back into 2P mode. (9)

## - CHOOSING A LENGTH OF TIME PER GAME (Refer to pics on troubleshooting sheet)

- 1. If power is OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. (1)
- 2. Hold down "BUTTON C & OK" simultaneously to enter configuration mode. (1)
- 3. Press button "T" until you find the desired time. (1) The times to choose are: 45 seconds (10), 90 seconds (1.5 minutes) (11), 180 seconds (3 minutes) (12), 270 seconds (4.5 minutes) (13) or 600 seconds (10 minutes). (14) Once chosen, hit "OK". (1)