



A-1 AMUSEMENT & PARTY RENTAL

17 SUNNYBROOK DR. CINCINNATI, OHIO 45237

PHONE: (513) 761-4386 FAX: (513) 761-8555

WWW.AMUSEMENTRENTAL.COM

DIGITAL PHOTO BOOTH

IT IS REQUIRED THAT THE DIGITAL PHOTO BOOTH HAS A PERMANENT SHELTER TO PROTECT FROM SUN AND THE RAIN. THIS COULD BE IN THE FORM OF A GARAGE, PARK SHELTER, OR INSIDE ROOM.

DO NOT MOVE, TURN OFF OR UNPLUG

IF YOU CHOOSE TO MOVE, TURN OFF OR UNPLUG THE DIGITAL PHOTO BOOTH ONCE IT HAS BEEN DELIVERED AND SET-UP, YOU ARE ASSUMING ALL RESPONSIBILITY FOR:

- DAMAGES TO THE MACHINE
- LOSS OF DATA
- DAMAGES TO PHOTOS

EVENT SET-UP

EACH EVENT IS SET-UP PER THE SELECTIONS THAT ARE COMPLETED BY THE CONTACT PRIOR TO THE EVENT. ANY CHANGES TO THE EVENT MUST HAVE BEEN COMPLETED PRIOR TO DELIVERY. NO CHANGES TO THE CHOICES CAN BE MADE ONCE THE DIGITAL PHOTO BOOTH IS DELIVERED.

ADJUSTING THE RING LIGHT

THE RING LIGHT CAN BE TURNED OFF/ON AND THE BRIGHTNESS CAN BE ADJUSTED BY TURNING THE KNOB TO THE DESIRED LEVEL. THE RING LIGHT KNOB IS LOCATED AT THE BACK AND BOTTOM OF THE RING LIGHT.

ADJUSTING THE SIDE LED LIGHTS

TO ADJUST THE SIDE LED LIGHTS, USE THE REMOTE THAT IS ATTACHED TO THE BACK OF THE BOOTH BY VELCRO. CHOOSE A SINGLE-COLOR BUTTON TO CHANGE THE SIDE LIGHTS A SOLID COLOR OR CHOOSE ONE OF THE ACTION BUTTONS (EX: FADE) TO SHOWCASE CHANGING/FLASHING COLORS. THE LED LIGHTS CAN BE TURNED OFF USING THE ON/OFF BUTTON ON THE REMOTE.

TEXT & EMAIL CAPABILITIES

ALL PHOTOS AND VIDEOS CAN BE SENT VIA TEXT/EMAIL DURING THE EVENT, IF THE CONTACT CHOSE THE OPTION(S) DURING THE SELECTION SET-UP. THE DIGITAL PHOTO BOOTH **DOES NOT** NEED WI-FI FOR USE. A-1 AMUSEMENT & PARTY RENTAL USES VERIZON DATA SERVICE TO SEND TEXTS AND EMAILS VIA THE DIGITAL PHOTO BOOTH. IF THE BOOTH IS SET-UP IN A LOCATION WITH LIMITED SERVICE, TEXTS/EMAILS MAY NOT SEND IN A TIMELY MANNER, BUT WILL BE STORED IN A QUEUE AND WILL NOT BE LOST. ONCE SERVICE IS RESTORED, THE QUEUE WILL BE SENT, WHETHER THAT IS DURING OR AFTER THE EVENT. ALL OF THE PHOTOS WILL ALSO BE STORED IN THE DIGITAL PHOTO GALLERY.

DIGITAL PHOTO GALLERY

ALL PHOTOS AND VIDEOS TAKEN DURING THE EVENT ARE STORED IN A DIGITAL PHOTO GALLERY. AFTER THE EVENT, A-1 AMUSEMENT & PARTY RENTAL WILL SEND THE DIGITAL GALLERY VIA EMAIL TO THE CONTACT GIVEN WITHIN 5 BUSINESS DAYS.

PRINTER AND PRINTER STAND

THE PRINTER WILL BE SET-UP AND LOCKED IN THE PRINTER STAND AT DELIVERY AND SET-UP. A KEY WILL BE MADE AVAILABLE FOR CUSTOMERS THAT WILL NEED TO CHANGE THE PHOTO PAPER DURING THE EVENT.

PHOTO PAPER

AT DELIVERY, THE PRINTER WILL BE LOADED WITH 1 ROLL OF PHOTO PAPER (150 4X6 PRINTS) AND FILM. IF YOU HAVE PURCHASED ADDITIONAL ROLLS OF PHOTO PAPER, YOU WILL BE RESPONSIBLE FOR CHANGING THE PHOTO PAPER AND FILM WHEN THE FIRST (AND EACH ADDITIONAL) ROLL RUNS OUT.

SCAN THE QR CODE TO VIEW A VIDEO WITH STEP-BY-STEP INSTRUCTIONS FOR CHANGING THE PAPER AND FILM.

NOTE: CUSTOMER IS RESPONSIBLE FOR ANY DAMAGE TO THE PRINTER OR FILM DURING THE FILM REPLACEMENT. A-1 RENTAL IS NOT RESPONSIBLE FOR ANY DAMAGE OR LOSS OF USE.



ACCESSORIES INCLUDED

DIGITAL PHOTO BOOTH # _____

PRINTER # _____

____ DIGITAL PHOTO BOOTH

____ PRINTER

____ POWER CORD

____ (1) ROLL/FILM (150 4X6 PRINTS) – INSTALLED

____ “BOOTH CLOSED” COVER

____ WIRELESS CONNECT MODULE

____ RUBBER FLOOR MAT

____ PRINTER STAND

____ BLACK CORD STORAGE BOX

____ RUBBER FLOOR MAT

____ ADDITIONAL PHOTO ROLL(S)/FILM # _____

I HAVE READ AND UNDERSTAND THESE RULES. I WILL SEE THAT THEY ARE ENFORCED.

NAME X _____

DATE _____

(PLEASE PRINT AND SIGN)

COMPANY REP X _____

DATE _____

*******RENTER IS RESPONSIBLE FOR ALL DAMAGES*******