



## A-1 AMUSEMENT & PARTY RENTAL

17 SUNNYBROOK DR. CINCINNATI, OHIO 45237

PHONE: (513) 761-4386 FAX: (513) 761-8555

[WWW.AMUSEMENTRENTAL.COM](http://WWW.AMUSEMENTRENTAL.COM)

## FROZEN DRINK MACHINE

**IMPORTANT:** THIS MACHINE IS DESIGNED FOR INDOOR USE. IF USING OUTDOORS, KEEP OUT OF DIRECT SUNLIGHT. THE HIGHER THE TEMPERATURE AND HUMIDITY, THE MORE DIFFICULT IT IS FOR THE MIX TO FREEZE. FOR BEST RESULTS AND FOR A TIMELY MIX FREEZE, USE INDOORS. CONTENTS WILL NOT FREEZE OUTSIDE IF TEMPERATURE IS ABOVE 80 DEGREES.

**WARNING:** DO NOT ADD ICE CUBES OR ANY FROZEN MIX TO THE MACHINE

### OPERATION INSTRUCTIONS

1. CAREFULLY PLACE UNIT UPRIGHT ON STABLE LEVEL SURFACE. DO NOT LAY UNIT ON ITS BACK OR SIDE AS DAMAGE TO THE COMPRESSOR MAY OCCUR.
2. CONNECT UNIT TO THE POWER SUPPLY (110 V 20 AMP GROUNDED CIRCUIT).  
**NOTE: ALL CONCESSION EQUIPMENT SHOULD BE OPERATED ON ITS OWN 20 AMP/110V CIRCUIT! IT'S RECOMMENDED THAT THE UNIT BE PLUGGED DIRECTLY INTO THE ELECTRIC OUTLET.**
3. FILL THE DISPENSING BOWL WITH THE DESIRED LIQUID PRODUCT (2 ½ GALLONS MAXIMUM). DO NOT OVERFILL THE TANK. THIS UNIT CAN BE USED TO DISPENSE SODAS, GATORADE, APPLE CIDER, DRINK MIX, ETC.  
**NOTE: BEFORE FILLING, ENSURE DISPENSING BOWL IS FULLY SEATED AND SEALED. (HINT: IF YOU ARE NOT SURE IF THE BOWL IS PROPERLY SEATED, YOU CAN TEST IT BY POURING IN SOME WATER FIRST.)**
4. IF USING OUR DRINK MIX, FOLLOW MIXING INSTRUCTIONS ON DRINK MIX CONTAINER. IF ADDING ALCOHOL, EXCHANGE WITH ONE PART WATER (1/2 GALLON).
5. TO OPERATE, PRESS MAIN POWER SWITCH, WHICH WILL TURN ON THE AGITATOR, AND SELECT YOUR DESIRED CONSISTENCY.
  - FOR SLUSH, PRESS THE COOLER SWITCH TO "SNOWFLAKE" POSITION.
  - FOR CHILLED BEVERAGE, PRESS THE COOLER SWITCH TO "MOON" POSITION.
6. ALLOW 1 ½ TO 2 HOURS FOR THE PRODUCT TO FREEZE. IF YOU ARE OUTSIDE OR MIXING WITH ALCOHOL, ALLOW ADDITIONAL TIME.
7. TO DISPENSE THE PRODUCT, GENTLY PUSH OR PULL THE DISPENSING HANDLE. USING TOO MUCH FORCE CAN BREAK THE DISPENSING HANDLE.

### CLEANUP INSTRUCTIONS

**NOTE:** NO DISASSEMBLY REQUIRED.

1. TURN UNIT OFF AND UNPLUG FROM POWER SOURCE.
2. DRAIN MACHINE OF ANY LEFTOVER PRODUCT.
3. RUN COLD WATER THROUGH UNIT AND DRAIN.

**\*\*\*\*RENTER IS RESPONSIBLE FOR ALL DAMAGES\*\*\*\***