

# TROUBLESHOOTING ONLY

## - VERIFY LIGHT SENSORS ARE LINKED TO SCOREBOARD

1. If power OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. **(1)**
2. Hold down "BUTTON A" **(1)**
3. All light sensors should be blue. If light sensors are showing anything other than blue, proceed to "Adding Light Sensors" below.

## - TO CHECK BATTERY STATUS OF LIGHT SENSORS AND SCOREBOARD

1. If power is off, hold POWER button down for 4 seconds or until the scoreboard lights up. **(1)**
2. Hold down "BUTTON B" **(1)**
3. The battery charge level for the scoreboard is shown as a percentage on the screen. **(5)**
4. The battery charge level for each light sensor is represented as a lighted color as shown **(2)**

## - RESETTING ALL LIGHT SENSORS

1. If power is OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. **(1)**
2. Hold down "BUTTON C & D" simultaneously to enter configuration mode. **(1)** All linked light sensors will blink blue ONLY when in configuration mode. You will see "CO nF" on the scoreboard when in configuration mode. **(3)**
4. Press and hold "BUTTON C" for 5 seconds. **(1)** All light sensors, at this time, will not be functional with this scoreboard.
5. Press POWER button once to exit configuration mode.
6. To pair or sync the light sensors back up with this scoreboard, or a different scoreboard, follow instructions below for "ADDING LIGHT SENSORS".

## - ADDING LIGHT SENSORS TO SYNC WITH SCOREBOARD

1. If power is OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. **(1)**
2. Hold down "BUTTON C & D" simultaneously to enter configuration mode. **(1)** All linked light sensors will blink blue ONLY when in configuration mode. You will see "CO nF" on the scoreboard when in this mode. **(3)**
4. Press and hold "BUTTON A" for 5 seconds. **(1)** "PA Ir" will appear on the scoreboard. **(4)**
5. Place hand on one of the light sensors. The light sensor will turn red. Wait for 15 seconds OR until the light sensor turns green.
6. Repeat for all light sensors until you see all light sensors green.
7. Press POWER button once to exit configuration mode. **(1)**
6. To verify that all light sensors are synced, press and hold "BUTTON A". **(1)** All synced sensors will be blue.

## - WHEN CHARGING AND NO SENSORS ARE LIT UP

1. If power is OFF, hold POWER button down for 4 seconds or until the scoreboard lights up. **(1)**
2. Hold down "BUTTON C & D" simultaneously to enter configuration mode. **(1)** All linked light sensors will blink blue ONLY when in configuration mode. You will see "CO nF" on the scoreboard when in this mode. **(3)**
3. Press and hold "BUTTON D" **(1)** until you see "On" on the scoreboard. **(6)**
4. Press power button once to exit mode. **(1)**
5. All linked light sensors should light up to indicate charging.

**NOTE: WHEN CHARGED OVERNIGHT, ALL LIGHT SENSORS WILL BE GREEN OR BLUE WHEN FULLY CHARGED.**

