



A-1 AMUSEMENT & PARTY RENTAL

17 SUNNYBROOK DR. CINCINNATI, OHIO 45237

PHONE: (513) 761-4386 FAX: (513) 761-8555

WWW.AMUSEMENTRENTAL.COM

HOT DOG ROLLER GRILL

Note: All concession equipment should be operated on it's own 20 amp/110v circuit!

1. Make sure drip pan is under rollers.
2. Plug in and turn rollers on. The heat is controlled with 2 separate temperature dials. One for the front half of the grill, and one for the back half.
3. Turn temperature on to "High" for 10 minutes to pre-heat grill, then adjust heat to desired cooking temperature.
4. Place hot dogs on grill and cook to taste.
5. When finished turn off the heat and rollers. Unplug.

Unit will hold up to 20 regular sized hot dogs.

*****RENTER IS RESPONSIBLE FOR ALL DAMAGES*****

HOT DOG ROLLER GRILL CHECKLIST

Unit Number: _____

OPERATION CHECK:
APPLICABLE

√ = "OK"

X = "SEE NOTES"

N/A = "NOT"

INSPECT POWER CORD FOR WEAR/MISSING PINS

ROLLERS ROTATE

FRONT ROLLERS HEAT

BACK ROLLERS HEAT

BEFORE PUTTING ON SHELF:

DRIP PAN

NOTES/ACTION TAKEN:

TIME: ____ : ____ A.M. / P.M.
(circle one)

NAME: _____ DATE: ____ / ____ / ____